


PICNIC BENCHES




Assembly Instruction for Single Seater Merlin (2-person assembly recommended)

Basic tools required: Cordless screwdriver/drill-Pozidrive no2 bit,

13mm socket or spanner.



R/H End Frame x 1 L/H End Frame x 1






Fixing List:

24No 5.0x70mm Screws

4No 100mm Washer Head Screws

- 1) Check the component and fixing list ensuring that you have all the required items.
- 2) Stand 2 End Frames and place a Seat Base A (526mm panel) in between the 2 end frames at the front and screw using 4No 5.0x70mm screws as shown in Picture 1. Repeat this for the back of the seat.
- 3) Take 2No 100mm screws and screw them into the 2 pre-drilled holes in the end frame so that they are just protruding through the other side, after this place the seat back onto the screw and tighten. Repeat this for both sides. Use picture 2 for reference.
- 4) Next, get 4No 5.0x70mm Screws and screw them into the predrilled holes on the Seat Base A (526mm) as shown in Picture 3. Repeat this step but using the Seat Base B (602mm) panels instead, making sure they are spaced out evenly (approx. 8mm gap).
- 5) Once all steps have been completed the bench should look as shown in Picture 4.



Picture 4

