




5) Take the 4 seat sections and align them as shown in Picture 5 with the predrilled holes aligning as shown as well in Picture 5. Then with 2No 5.0x100mm Screws per brace drill them into these holes as shown in Picture 5.




6) Next, take the Table Leg and align this with the hole in the Cross Brace as stated out in Picture 6, making sure that the other hole on the Table Leg is at the top and that the Table Leg is to the left of the Cross Brace. Insert a M8 90mm bolt and use a washer, a nut and then a dome nut to secure, please note that the table legs shouldn't touch the floor. Repeat this process for the other table legs.




7) Place the table top in position as shown in Picture 7 with the table blocks lining up with the hole on the Table Leg, also making sure that the table block is to the right of the Table Leg. Once the holes are lined up place a 90mm bolt through the predrilled holes, then tighten using washers and nuts. Repeat this step for every table block and Table Leg.



8) Place 1No 5.0x70mm Screw into the predrilled hole of the Seat Cross Brace as shown in Picture 8 in order to further secure the table together. Repeat this step for all of the Seats. Once this has been completed make sure that all screws and bolts are fully tightened.



9) Once all steps have been completed the table should look like Picture 9.



# PICNIC BENCHES



Assembly Instruction for Junior Round Picnic Bench (2-person assembly recommended)

Basic tools required: Cordless screwdriver/drill-Pozidrive no2 bit, 5mm wood drill bit, 13mm socket or spanner.

## Component List:




Table Top x 1




Table Leg x 4



Seat Leg x 8



Seat Cross Brace x 4



Seat x 4



Cross Brace x 4

## Fixing List:


28No 5.0x70mm Screws

16No 5.0x100mm Screws


8No 90mm M8 Bolts & Nuts

8No Washers

4No Dome Head Nuts




Picture 1




Picture 2

Predrill and screw



Picture 3

Flush with back of seat



Picture 4

Predrill and screw

1) Check the component list, making sure that you have everything required.

2) Firstly, you will need to make the H sections for the seats, to do this you will have to take a 5.0x100mm Screw and drill it into the predrilled seat leg hole and align with the predrilled hole of the Seat Cross Brace, don't fully tighten the screws at this stage. Repeat this step for the opposite side to make the H section as shown in Picture 1. Then repeat 4 times to make 4 H sections.

3) Once the H sections have been completed, align them as shown in Picture 2 with the Seat Leg fitting with the middle section of the seat, also making sure that the angle of the Seat Cross Brace also matches that of Picture 2. Then predrill the Seat Leg to secure the H section to the seat block with the hole positions being stated in Picture 2, then 2No 5.0x70mm Screws need to be drilled into these holes. Repeat this for all 4 seats.

4) Take one Cross Brace, ensuring that the undrilled edge of the Cross Brace is flush with the back of the Seat as shown in Picture 3. Once this has been completed predrill and screw 2No 5.0x70mm Screws into the side of the seat block as demonstrated in Picture 4. Repeat this for all of the Cross Braces ensuring that the undrilled end of the Cross Brace is flush with the back of the seat.